

## 4300 Service Parts List (cont'd)

Ref. No.	Description	4347	4348	4353	4354	4370	4371	4372	4373	4374	4381	4392	Qty. Used
1	Cotter pin	M2556-10	M2556-10	M2556-10	M2556-10	M2556-10	M2556-10	M2556-10	M2556-10	M2556-10	M2556-10	M2556-10	1
2	Nut	M3019	M3019	M3019	M3019	M3019	M3019	M3019	M3019	M3019	M3019	M3019	1
3	Washer	M3172	M3172	M3172	M3172	M3172	M3172	M3172	M3172	M3172	M3172	M3172	1
4	Impulse coupling assembly	—	—	—	M3529	—	M3163	M3100	M3529	M3689	M3007	M3939	1
5	Oil seal	M3062	M3062	M3062	M3062	M3062	M3062	M3062	M3062	M3062	M3062	M3062	1
6	Air vent	M1077	M1077	M1077	M1077	M1077	M1077	M1077	M1077	M1077	M1077	M1077	1
7	Frame	M3900	M3900	M3900	M3859	M3900	M3859	M3859	M3859	M3888	M3859	M3888	1
8	Rotor	M3548	M3513	M3548	M3158	M3548	M3158	M3158	M3158	M3065	M3158	M3065	1
9	Bearing kit	K3301	K3301	K3301	K3301	K3318-4	K3318-4	K3318-4	K3318-4	K3318-4	K3318-4	K3318-4	1
10	Ball bearing	M3006	M3006	M3006	M3006	M3006	M3006	M3006	M3006	M3006	M3006	M3006	1
11	Bearing cap assembly	K3630	K3630	K3630	K3630	K3485	K3485	K3485	K3485	K3485	K3485	K3485	1
12	Bearing cap clamp	M3018	M3018	M3018	M3018	M3018	M3018	M3018	M3018	M3018	M3018	M3018	2
13	Screw	M3221-10	M3221-10	M3221-10	M3221-10	M3221-10	M3221-10	M3221-10	M3221-10	M3221-10	M3221-10	M3221-10	2
14	Contact point primary	M3637	M3637	M3637	M3637	M3081	M3081	M3081	M3081	M3081	M3081	M3081	1
15	Contact point secondary	M3637	M3637	M3637	M3637	—	—	—	—	—	—	—	1
16	Rotor gear	M3827	M3827	M3827	M3827	M3827	M3827	M3827	M3827	M3827	M3827	M3827	1
17	Woodruff key	M2536	M2536	M2536	M2536	M2536	M2536	M2536	M2536	M2536	M2536	M2536	1
18	Coil wedge	M3040	M3040	M3040	M3040	M3040	M3040	M3040	M3040	M3040	M3040	M3040	2
19	Screw	M3020-10	M3020-10	M3020-10	M3020-10	M3020-10	M3020-10	M3020-10	M3020-10	M3020-10	M3020-10	M3020-10	1
20	Coil	K3975	K3975	K3975	K3975	K3975	K3975	K3975	K3975	K3975	K3975	K3975	1
21	Screw	M2555-10	M2555-10	M2555-10	M2555-10	M2555-10	M2555-10	M2555-10	M2555-10	M2555-10	M2555-10	M2555-10	1
22	Air vent with hood	M3084	M3084	M3084	M3084	M3084	M3084	M3084	M3084	M3084	M3084	M3084	1
23	Screw	M3015-10	M3015-10	M3015-10	M3015-10	M3015-10	M3015-10	M3015-10	M3015-10	M3015-10	M3015-10	M3015-10	3
24	Housing, distributor	M3832	M3832	M3832	M3832	M3902	M3902	M3902	M3902	M3874	M3874	M3902	1
25	Capacitor	K3984	K3984	K3984	K3984	K3984	K3984	K3984	K3984	K3984	K3984	K3984	1
26	Distributor block and gear assembly	K3822	K3822	K3822	K3822	K3822	K3822	K3822	K3822	K3822	K3822	K3822	1
27	Carbon brush	M3215	M3215	M3215	M3215	M3215	M3215	M3215	M3215	M3215	M3215	M3215	1
28	Washer	M2532-10	M2532-10	M2532-10	M2532-10	M2532-10	M2532-10	M2532-10	M2532-10	M2532-10	M2532-10	M2532-10	1
29	Screw	M3021-10	M3021-10	M3021-10	M3021-10	M3021-10	M3021-10	M3021-10	M3021-10	M3021-10	M3021-10	M3021-10	2
30	Spacer	M3826-10	M3826-10	M3826-10	M3826-10	M3826-10	M3826-10	M3826-10	M3826-10	M3826-10	M3826-10	M3826-10	2

SLICK 4300 MAG PARTS

