

Window Replacement Tooling for Boeing Aircraft

Windows in your aircraft are the way the flying public sees the world. A great view makes a special flight even more magical. Pacific Tool manufactures a host of Boeing-designed tools to ensure the windows of your aircraft remain in tip-top condition.

ST1742F



Window Manipulator

Used to manipulate passenger window assemblies during installation and placement of locking clips. Plastisol coated to prevent damage to the window while tool is in contact with the assembly.

ST1742F-1



Installation/Removal Tool

Used to aid in the installation and removal of securing clips on 787 passenger windows. Compact design allows access to all areas of the window.



ST1742G-1

Removal Tool

Used to gain leverage inside window seals and behind locking clips during window removal.

ST1066-21



Seal Alignment Tool

Used to align window gaskets without removing the window frame. This tool's extension length and shape have been designed to access all areas of the gasket and ensure proper sealing.



ST2580-258B-2

Latch Assembly Socket

Used to adapt standard ½" torque wrench to tighten section 41 window latch assemblies. Ensures proper tightening of the latch without any damage.

For more information, call: 1-800-284-2551

North America & AOG: 1-888-322-2589 International Sales: +1-972-586-1566 shop.boeing.com/aviation-supply